

R600 // SECONDARY AIR INTAKE DRILLING TEMPLATE



- 1) Place Template so this Contour Line is Matching the Airbox Line.
- 2) Once aligned Tape down.
- 3) Tape down remaining template on the outside of the airbox and drill holes accordingly as per the centre points.

